

KitchenAid®

Cordless Variable Speed Hand Blender


MODELS:

5KHBBV83AAC0 (Almond Cream)

5KHBBV83ABM0 (Black Matte)

5KHBBV83AER0 (Empire Red)

BLENDER PARTS



BLENDER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4	W11413685	4 Cup Pitcher with Lid
	W11419339	Use & Care Guide	5	W11413711	Chopper Attachment
2		Blending Arm Assembly	6		Whisk Assembly
	W11413702	Almond Cream		W11413716	Polished Finish
	W11413703	Black Matte		W11413719	Textured Finish
	W11413700	Empire Red	7	W11413725	Charger
3	W11413707	Pan Guard			