


2 - SLICE AND 4 - SLICE TOASTER

MODELS:

5KMT221EOB0 (Onyx Black - European)
5KMT221EER0 (Empire Red - European)
5KMT221EAC0 (Almond Creme - European)
5KMT221ECU0 (Contour Silver - European)
5KMT221BOB0 (Onyx Black - Britain)
5KMT221BER0 (Empire Red - Britain)

5KMT221BAC0 (Almond Creme - Britain)
5KMT221BCU0 (Contour Silver - Britain)
5KMT421EER0 (Empire Red - European)
5KMT421EAC0 (Almond Creme - European)
5KMT421BER0 (Empire Red - Britain)
5KMT421BAC0 (Almond Creme - Britain)

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10625929	Use and Care Guide

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	W10673684	Tray, Crumb (for 2 Slice)
3	W10673683	Knob, Control

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10673685	Tray, Crumb (RT)
5	W10673686	Tray, Crumb (LT)