

# PARTS LIST

for

# **KitchenAid<sup>®</sup>** **4 - SLICE TOASTER -** **INTERNATIONAL**

## Models:

**5KMT4205EOB0 (Onyx  
Black - European)**

**5KMT4205ECA0 (Candy  
Apple - European)**

**5KMT4205EMS0  
(Medallion Silver -  
European)**

**5KMT4205EFP0  
(Frosted Pearl -  
European)**

**5KMT4205EAC0  
(Almond Creme -  
European)**

**5KMT4205EER0  
(Empire Red -  
European)**

**5KMT4205BOB0 (Onyx  
Black - Britain)**

**5KMT4205BCA0 (Candy  
Apple - Britain)**

**5KMT4205BMS0  
(Medallion Silver -  
Britain)**


**5KMT4205BFP0  
(Frosted Pearl - Britain)**

**5KMT4205BAC0  
(Almond Creme -  
Britain)**

**5KMT4205BER0  
(Empire Red - Britain)**

**FOR CUSTOMER SATISFACTION ALWAYS USE  
FACTORY SPECIFICATION PARTS**

# UNIT PARTS



# UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10506838	Use and Care Guide
2	W10570463	Board, Control PCBA
3		Tray, Crumb (Left)
	W10539054	Onyx Black
	W10539052	Candy Apple
	W10539053	Medallion Silver
	W10539051	Frosted Pearl
	W10570462	Almond Creme
	W10570461	Empire Red
4		Tray, Crumb (Right)
	W10539050	Onyx Black
	W10539043	Candy Apple
	W10539048	Medallion Silver
	W10539042	Frosted Pearl
	W10570460	Almond Creme
	W10570459	Empire Red
5	W10532148	Foot, (Includes Front and Rear)
6		Housing
	W10570470	Onyx Black
	W10570468	Candy Apple
	W10570469	Medallion Silver
	W10570467	Frosted Pearl
	W10570466	Almond Creme
	W10570465	Empire Red
7	W10567060	Warmer, Bun
8	W10567062	Rack, Sandwich
9	W10567063	Handle, Slider