




KitchenAid®

K150 BLENDER

MODELS:

- 5KSB1325EAC0 (Almond Cream)
- 5KSB1325EBM0 (Black Matte)
- 5KSB1325EDG0 (Matte Charcoal Grey)
- 5KSB1325EER0 (Empire Red)
- 5KSB1325EOB0 (Onyx Black)
- 5KSB1325EPA0 (Passion Red)
- 5KSB1325EVB0 (Blue Velvet)


JAR ASSEMBLY PARTS



JAR ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11280085	Lid Assembly
2	W11247566	Pad, Jar
3	W11507339	Jar Assembly

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		Upper Base	9	W10276642	Screw
	W11344949	Owner's Manual		W11305916	Onyx Black	10	W11405619	Electronic Control
2	W11105854	Trimband		W11447269	Empire Red	11	W11365580	Power Cord
3	W11219397	Plug, Coupler		W11403513	Almond Cream	12	W11238803	Reed Switch
4	W11214276	Bezel, Rotary Switch		W11265192	Black Matte	13	W11294881	Coupler
5	697773	Screw		W11212371	Matte Charcoal Grey	14	W11174445	Screw, Coupler
6	W11357978	Knob, Rotary Switch		W11212375	Blue Velvet	15	W11214248	Motor
7	W11180765	Base		W11265191	Passion Red	16	9709366	Seal, Motor